

PARTS INCLUDED:

- 2X TRAINING WHEELS •2X WHEEL SPACERS
- 2X M10 X 60MM ½ THREAD BOLTS •1X TRAINING WHEEL AXLE
- 2X EXTENDED PEG BOLTS •2X AXLE MOUNT BRACKETS
- 2X AXLE MOUNT CAPS •4X M6 X 15MM BOLTS



WARRIOR KIDS TRAINING WHEELS - INSTALLATION GUIDE

TOOLS REQUIRED:

- 2X 5MM ALLEN BITS/ALLEN KEYS
- 1X 8MM ALLEN BIT/ALLEN KEY
- LOCTITE

STEP 1:

REMOVE THE FOOTPEG PINS FROM EITHER SIDE OF THE BIKE, MAKING SURE TO KEEP HOLD OF THE SPRINGS FOR REFITTING LATER.



STEP 2:

USING THE EXTENDED PEG BOLTS, ATTACH THE AXLE MOUNT BRACKETS TO THE LEFT AND RIGHT FOOT PEG MOUNTS (NOT SIDED), FITTING THE SPRINGS BACK ON IN THE SAME POSITION AS THE WERE REPLACED, MAKING SURE TO HAVE BOTH MOUNT BRACKETS IN THE SAME POSITION.

STEP 3:

USING THE 4X M6 X 15MM, (2 EITHER SIDE) LOOSELY ATTACH THE AXLE MOUNT CAPS, THEN SLIDE THE TRAINING WHEEL AXLE THROUGH BOTH MOUNTS, USING THE MARKINGS ON THE AXLE TO MAKE SURE IT IS CENTRAL TO THE BIKE AND THEN TIGHTEN TO THE AXLE MOUNT CAPS TO HOLD THE TRAINING WHEEL AXLE IN PLACE.



STEP 4:

FINALLY, FIT BOTH LEFT AND RIGHT TRAINING WHEELS (NOT SIDED), MAKING SURE TO PLACE THE WHEEL SPACER BETWEEN THE WHEEL AND THE TRAINING WHEEL AXLE. APPLY LOCTITE TO THE M10 X 60 BOLT AND TIGHTEN DOWN.